

# Body Mount Chop Instructions

1: Factory Left side Body Mount



2: Cut out template and place along front facing edge of the body mount.



3: Transfer mark onto frame.



4: Use rear template on back side of body mount and transfer that mark as well.



5: Using filler plate as a guide remove material back to your mark line, leaving upper frame material matching the curved plate as to not disturb factory body mount.



6: Tack filler plate onto frame. Prep surrounding area for paint, Finish weld and spray with paint on the plate and frame while it's warm.



7: Repeat for passenger side by flipping templates over.

All products built and designed by InSain Fabrication, LLC are intended for off-road use and should be assembled, installed, and used in accordance with InSain Fabrication, LLC recommendations. InSain Fabrication, LLC provides this kit as a template to help you achieve the cleanest most efficient body mount chop possible. We will not be held liable for any inaccuracy or damage done by the use of this product.