



Front Diff Drop Kit

95-04 Tacoma, 96-02 4Runner, 00-06 Tundra



1. Remove skid plate from front of the vehicle, save the OEM bolts.
2. Support the differential with a floor jack
3. Remove factory M14 bolts and nuts, supporting the front differential, see Fig. 1 above for the stock configuration. Save the OEM dome washers for re installation.
4. Lower differential far enough to allow insertion of the 1" drop spacers. You may need to pull down on the differential.
5. Install the 1" spacers between the two front differential supports and front cross-member. See photo above.
6. Fasten to cross-member using new 1/2" x 6" long Grade 8 bolts and nuts (making sure to reuse the factory dome washers). Tighten to the factory specifications. If you don't have the factory specs, 70-90 ft.lbs should be adequate.
7. Install the front skid plate using the OEM bolts on the front and the supplied longer bolts with washers and spacers on the rear. Skid plate trimming may be required on some models.
8. Torque all skid plate bolts to factory specifications. 25 ft lbs should be adequate.