



## BPV-K INSTALLATION

[Support@toyteclifts.com](mailto:Support@toyteclifts.com)

Read all of the installation instructions prior to ToyTec Lifts BPV-K installation.  
ToyTec Lifts L.L.C. recommends that this be installed by a certified auto technician

1. Park the Vehicle on a level concrete surface.
2. Unbolt the brake proportioning valve bracket that is located on the backside of the rear axle. Save the stock hardware as these parts will be reused.
3. Using the stock bolts, bolt the bottom two holes of the BPV-K bracket to the rear axle.
4. Using the provided hardware install the brake proportioning valve to the new BPV-K bracket.
5. Tighten the stock and provided hardware to stock torque specs.



**WWW.TOYTECLIFTS.COM**